



Application Instructions:

- 1.) Chase out a reglet approx. 30 x 30 mm along the construction joints. Fill the reglet with **VANDEX UNI MORTAR 1**, such that it is flush with the surface, at a rate of approx. 1.8 kg/linear meter.
- 2.) Apply one coat of **VANDEX SUPER**, 1.2 kg/m² to the slab surface.
- 3.) To the interior wall surfaces apply two coats of **VANDEX SUPER**, at the total rate of 1.5 kg/m².
- 4.) Apply one coat of **VANDEX SUPER**, 1.2 kg/m² to the slab surface.

Note:

Where a better aesthetic appearance of the waterproofing treatment is desired, use equivalent amounts of **VANDEX SUPER WHITE** in steps 2.) and 3.)

The information contained herein is based on our longterm experience and the best of our knowledge. We can, however, make no guarantee since for a successful outcome, all circumstances in an individual case must be taken into consideration. Indications of quantities required are only averages which in certain cases might be greater.