



Application Instructions:

- 1.) Locate leak in the concrete
- 2.) Cut out the leak to sound concrete - min. depth of 10 cm and of such a diameter that for instance a hammer handle will easily enter. (Note the conical shape of the cavity). Carefully clean and wash out the cavity.
- 3.) Form a plug made of **VANDEX PLUG** or **VANDEX SUPER** mixed with **VANDEX QUICKBINDER** according to relevant data sheets. Press the plug into the hole and maintain pressure until setting has taken place.
- 4.) Slurry coat the remaining part of the cavity with **VANDEX SUPER**, 1.5 kg/m².
- 5.) Before the **VANDEX SUPER** coat is completely set fill the rest of the cavity with **VANDEX UNI MORTAR 1**.
- 6.) When the mortar has set apply Vandex surface waterproofing treatment according to relevant Vandex Specification.

Remark: For severe leaks use plugging method with drain according to relevant data sheet (**VANDEX QUICKBINDER**)

The information contained herein is based on our longterm experience and the best of our knowledge. We can, however, make no guarantee since for a successful outcome, all circumstances in an individual case must be taken into consideration. Indications of quantities required are only averages which in certain cases might be greater.