



Remarks: - Substrate adhesion strength > 1.5 N/mm<sup>2</sup>  
 - Salt treatment depending on salt analysis results

### Application Instructions:

- 1.) Chase out a reglet approx. 30 x 30 mm along the slab-wall junction and point with VANDEX UNI MORTAR 1 Z.
- 2.) Depending on the salt analysis results, treat with VANDEX MINERALIT.
- 3.) Apply one coat VANDEX UNI MORTAR 1 Z, at the rate of 20 kg/m<sup>2</sup> (10 mm) as a waterproofing layer. Depending on salt analysis results, incorporate VANDEX ANTI SULPHATE.
- 4.) Apply an open textured VANDEX ROUGH CAST as a bonding bridge, covering 50 % of surface whilst the VANDEX UNI MORTAR 1 Z is still green.
- 5.) As a finish, apply VANDEX REFURBISHMENT PLASTER white.
- 6.) Apply Vandex surface waterproofing treatment to the basement slab.
- 7.) Where appropriate install a horizontal damp-proof course with VANDEX INJECTION MORTAR (VIM) or VANDEX DPC INJECTION N°2.
- 8.) Treat the splash zone with one coat of VANDEX UNI MORTAR 1 Z, applied at the rate of 20 kg/m<sup>2</sup> (10 mm).
- 9.) Apply the Vandex refurbishment plaster system.

The information contained herein is based on our longterm experience and the best of our knowledge. We can, however, make no guarantee since for a successful outcome, all circumstances in an individual case must be taken into consideration. Indications of quantities required are only averages which in certain cases might be greater.